

Vesta Building Controller

8-Channel Central Control for Sun Protection and
Roller Shutter Systems in large Buildings

Installation and Operating Instructions



Introduction		page 43
1 Installation instructions		page 44
1.1	Mounting the Vesta Building Controller	page 44
1.2	Connecting the Vesta Building Controller	page 45
1.2.1	Mains power supply and relay outputs	page 45
1.2.2	Sensor connections and digital inputs	page 46
1.2.3	Wind speed sensors	page 46
1.2.4	Wind direction sensor	page 47
1.2.5	Temperature sensors	page 47
1.2.6	Sun sensors	page 47
1.2.7	External up/down inputs	page 48
1.2.8	Window cleaning and maintenance inputs	page 48
1.2.9	Rain sensor	page 48
1.2.10	Fire input	page 48
1.2.11	Signaling relay output	page 48
1.3	Communication ports	page 49
1.3.1	CAN	page 49
1.3.2	SSC	page 49
1.3.3	RS232	page 49
1.3.4	LON	page 49
2 General		page 50
2.1	Keys	page 50
2.1.1	Function keys	page 50
2.1.2	Cursor movement keys	page 50
2.1.3	Home key	page 51
2.1.4	Edit keys	page 51
2.2	Display	page 51
2.3	Buzzer	page 51
3 Operation		page 52
3.1	Main menu	page 52
3.2	Measured values	page 52
3.3	State of functions	page 53
3.3.1	Detailed functional description of current group	page 53
3.3.2	Changing current group	page 54
3.3.3	Active function overview	page 54
3.3.4	Example	page 55
3.4	Control	page 55
3.4.1	Control menu – by hand function	page 56
3.4.2	Control menu – by sun function	page 56
3.4.3	Type of control	page 56
3.4.4	Screen layout	page 56
3.4.5	Changing current group	page 56
3.5	Configuration	page 57
3.6	Logfile	page 57
3.6.1	Browsing the logfile	page 57
3.7	Info	page 58

Contents

4 Configuration		page 59
4.1 Password		page 59
4.1.1 How to enter the password		page 59
4.2 User interface		page 60
4.3 Time and date		page 61
4.3.1 Set time		page 61
4.3.2 Set date		page 61
4.3.3 Function keys		page 61
4.4 Groups		page 62
4.5 Change password		page 62
4.6 Sensors		page 63
4.6.1 Sun sensors		page 63
4.6.2 Temperature sensors		page 64
4.6.3 Wind sensors		page 64
4.6.4 Wind direction sensor		page 65
4.7 Functions		page 65
4.7.1 Tilting function		page 65
4.7.2 Sun function		page 67
4.7.3 Temperature function		page 68
4.7.4 Wind function		page 69
4.7.5 Wind direction function		page 70
4.7.6 Rain function		page 71
4.7.7 Window cleaning function		page 71
4.7.8 External inputs function		page 72
4.7.9 Hand function		page 72
4.7.10 Fire function		page 73
4.7.11 Clock function		page 74
5 Troubleshooting		page 75
6 Technical data		page 76

Introduction

The Vesta Building Controller is a microprocessor-based 8-channel central control system for all types of sun protection and roller shutter systems. The control is designed for use in large buildings with several facades and/or multiple storeys.

Depending on sun intensity, wind speed, wind direction, precipitation and current time, all connected sun protection and shutter systems can be controlled centrally. External systems such as security window systems, fire alarm or building services control systems can be easily integrated.

The sensor inputs allow simultaneous connection of:

- 2 anemometer
- 1 wind direction meter
- 8 sun sensors
- 2 temperature sensors
- 1 heated rain and frost sensor
- 8 group keys
- 8 maintenance switches
- 1 potential-free alarm input.

The user-friendly interface of the Vesta Building Controller (further mentioned as VBC) gives access to a lot of information like the measured sensor values, state of functions and a logfile. It also gives access to a lot of control possibilities like manual operation, automatic operation and control by the sun function. The display is divided in different area's containing plain text sometimes in combination with graphics. The function keys at the right side of the display give direct access to special functionality. The function keys are menu specific, which means that each menu can have its own set of function keys.

The VBC is prepared for the future, it has the possibility to connect to a LON-bus, it is prepared to connect to the CAN-bus, and it is also prepared to communicate with other VBC's. Connecting the VBC to a PC gives you the ability to control the VBC from your own workspace. Visualisation software gives you a direct overview and the possibility to control your complete building.


The next chapters will explain how to control the VBC, the different menus and how to configure the different functionality's.

Installation instructions

1 Installation instructions


1.1 Mounting the Vesta Building Controller

There are two ways to fix the Vesta Building Controller to the wall. The first is fixing it directly to the wall using the 4 mounting holes on the inside of the box (see picture 1). Remove the 2 covers on the top and bottom and fix the device to the wall with 4 screws. The drill distances are shown below.



The second option is to use the 2 spacers. These can be used to create a distance of 11 mm between the wall and the Vesta Building Controller. This allows cables to be guided behind the device, or fixing it on an uneven wall.

Attach the spacers on the back of the device as shown in picture 2 with the 4 screws which are included. Then fix the device to the wall using the holes on the corners. The drill distances are shown below.




Installation instructions

1.2 Connecting the Vesta Building Controller

The inputs and outputs of the Vesta Building Controller are under the two covers and are split up in two parts. On the upper part all the sensors are connected. The lower part is for the relay outputs.

1.2.1 Mains power supply and relay outputs

The picture below shows the output part.




The mains power supply (230 V~, 50 Hz) for the device must be made on the connections 46 to 51. The connections 1 to 9 are internally connected and can be used for example to connect the minus of the 24 Volt.

The outputs are potential-free and can therefore be used for 230 V~ control voltage or 24 V~/=. For safety reasons it is not allowed to combine both 230 V and 24 V on the outputs. In that case use external relayboxes.

The group outputs (10–33) are split up in blocks of 4 relays or 2 groups. Each block has its own common. The commons are used to put a voltage on the relays. This voltage is switched on the up/down outputs. Because the commons of the different blocks are next to each other it is very easy to connect them together. Optional the blocking outputs (SP1–SP8) can be used to disable the individual control on relay-PCB's.

The next diagram shows the internal structure of the Vesta Building Controller's outputs, and a typical installation for 4 groups with 24 V control voltage and optional blocking (dotted line). Everything above the numbers is internal, and below is external.




Note: Do not forget to bridge the commons if necessary. In the above situation for example terminals 15 and 16 must be bridged.

Installation instructions

1.2.2 Sensor connections and digital inputs

All sensors are connected in the upper connection part as shown below. The next chapters will describe the connection for each sensor.



1.2.3 Wind speed sensors

There can be 2 wind speed sensors connected. These can be the current type or the frequency type sensor. If the heated sensors maximum current consumption is 100 mA, the sensor can be connected directly. An external power supply must be used, if the heated sensors current consumption is higher than 100 mA.

Current sensor with heating less than 100 mA:

The sensor can be directly connected to the VBC. Use terminals 108, 110 and 112 for sensor 1 and 109, 111 and 113 for sensor 2.

For sensor 1 jumper 1 (see picture) must be placed to the left.

For sensor 2 jumper 2 (see picture) must be placed to the left.

Current sensor with heating more than 100 mA:

The sensor cannot be directly powered by the VBC. Therefore an external power supply unit must be placed. Only the signal and ground must be connected to the VBC (110 and 112 for sensor 1 and 111 and 113 for sensor 2).

For sensor 1 jumper 1 (see picture) must be placed to the left.


For sensor 2 jumper 2 (see picture) must be placed to the left.

Frequency type sensor with or without heating:

Both with and without heating can be directly connected (provided that the heating consumes no more than 100 mA). Use terminals 108, 110 and 112 for sensor 1 and 109, 111 and 113 for sensor 2. If an external power supply must be used, do not connect terminal 108 and/or 109.

For sensor 1 jumper 1 (see picture) must be placed to the right.

For sensor 2 jumper 2 (see picture) must be placed to the right.



Installation instructions

1.2.4 Wind direction sensor

There can be 1 wind direction sensor connected to the VBC. This one can be a current type or a digital sensor. If the heated sensors maximum current consumption is 100 mA, the sensor can be connected directly. An external power supply must be used, if the heated sensors current consumption is higher than 100 mA.

Current sensor with heating less than 100 mA:

The sensor can be directly connected to the VBC. Use the 12 V (108 or 109) from the wind speed connection and connect the output of the sensor to North (115). Also connect the ground (119).

Jumper 3 must be placed to the left side.


Current sensor with heating more than 100 mA:

The sensor cannot be directly powered by the VBC. Therefore an external power supply unit must be placed. Only the signal (North = 115) and the ground (119) must be connected.

Jumper 3 must be placed to the left side.


Digital sensor with or without heating:

Both with and without heating can be directly connected to the VBC (provided that the heating consumes no more than 100 mA). Connect the wind direction sensor to terminals 114 to 119. For the heater power supply (max. 100 mA) terminals 108 or 109 from the wind speed can be used. Jumper 3 must be placed to the right side.




1.2.5 Temperature sensors

There can be 2 temperature sensors TS-01 connected to the VBC. The temperature sensor is connected between terminal 120 and 121 for sensor 1 or between terminal 122 and 123 for sensor 2. The sensors do not have a polarity and can therefore be connected in both ways.



1.2.6 Sun sensors

There can be 8 sun sensors SS30 connected to the VBC. The terminals are 124 to 139. 124 and 125 are for sensor 1, 126 and 127 are for sensor 2 etc. It is possible to use 1 wire for the 5 V (for 8 sensors 9 wires can be used instead of 16). The sensors do not have a polarity and can therefore be connected in both ways. Each sensor can be assigned to 1 or more groups.




Installation instructions

1.2.7 External up/down inputs

Each group has its own external up/down input. This inputs require a potential-free switch. It is possible to switch more inputs with the same switch at the same time.


Connect the switch to the desired input and the common terminals (140, 149, 150 or 159).



1.2.8 Window cleaning and maintenance inputs


The window cleaning/maintenance inputs can be used to block the sunshade in a specific position. This is very important when the windows are cleaned or maintenance is carried out. Each group has its own input.

Connect a keyswitch to the input and the common terminals 160 and 169. It is possible to connect more inputs to one keyswitch.



1.2.9 Rain sensor

The rain sensor is connected with 6 wires. The connections on the rain sensor 1–6 correspond with connections 170–175 on the VBC. With the 2 DIP-switches on the right of the terminal block the sensitivity of the rain sensor can be set.



1.2.10 Fire input

The fire input can be used to connect the VBC to a fire alarm system. Connect a normally open potential-free contact from the fire alarm system to terminals 176 and 177 of the VBC (see picture chapter 1.2.9). Note that if the input is not used, the terminals 176 and 177 must be bridged by a wire.

1.2.11 Signaling relay output

The signaling relay (terminals 178 and 179) can be used to signal errors or status to other systems. It is an potential-free relay output. This relay contact can only be used for low voltages, up to 40 Volt and maximum 1 A.

Installation instructions

1.3 Communication ports

The VBC has several communication ports, however not all of them are used at this moment. The next chapters will describe the functions.

1.3.1 CAN

This option is not used at this moment and cannot be used.

1.3.2 SSC

With the Master-Slave option this connection will be used. Connect the Master VBC with the Slave VBC parallel to the terminals 104 to 107. The maximum length is 3 meter.

1.3.3 RS232

The RS232 interface can be used for maintenance and visualization. There are two options to connect the cable, use a male 9-pin SUB-D connector or directly connect the cable to the 5 terminals. **Never use both at the same time!** If a standard RS232 cable is used it must be a 1 to 1 cable. The maximum length is 5 meter.



1.3.4 LON

The connector is used to connect the VBC to the Vestalon-system. The option is only available if the VBC is equipped with the Vestalon-module. The service pin and the red LED are only for configuring the network. For a more detailed description of the network we refer to the Vestalon operating instructions.




General

2 General

This chapter describes how to control the Vesta Building Controller in general. The different function keys will be explained, the layout of the display and the buzzer functionality will be described.

The picture below shows the user control of the Vesta Building Controller.



Picture 1: The user control

- | | |
|------------------------------|-------------|
| ❶ Display title area | ❷ Home key |
| ❷ Display main area | ❸ Edit keys |
| ❸ Display date/time area | ❹ Power LED |
| ❹ Display function keys area | |
| ❺ Function keys | |
| ❻ Cursor movement keys | |

2.1 Keys

2.1.1 Function keys ❹

The function keys are special keys. The functionality of the function key will be described by the area left to the function key. This could be plain text or a pictogram. When the area left to the function key is blank that means there is no functionality assigned to this function key. When the text or graphic left to the function key is grayed out a functionality is assigned to this function key but it is disabled.

The two most upper function keys have always the same functionality:

 Enter sub-menu. The current selected item is a sub-menu. By pressing this function key, the sub-menu will be entered.

 Leave sub-menu. By pressing this function key, the sub-menu will be left.

2.1.2 Cursor movement keys ❻

With the cursor movement keys the cursor of the current selection can be moved.

2.1.3 Home key ⑦

By pressing the home key, the program will return to the main menu. There is one exception, when the string edit is activated, the home key will leave the string edit mode.

2.1.4 Edit keys ⑧

With the edit keys, the value of the current selected variable can be changed. When the current selection is not a variable, nothing will happen.

2.2 Display

The display area is divided in a number of areas which have always the same functionality, the following sections:

Title area ① Shows the current menu title.

Main area ② Shows the current menu. When a scrollbar is visible to the right of the main area means that the current menu has some items which are not visible. The size of the shutter represents the visible area, the position of the shutter indicates the current position. The current selection can be changed by pressing the cursor movement keys.

Date/time area ③ Shows the current day of week, date and time.

Function key area ④ Shows the functionality of the function key to the right side. The functionality can be shown by a icon or by plain text.

2.3 Buzzer


The buzzer will beep shortly to confirm that a key is pressed by the user. The volume of the buzzer can be changed in the configuration menu section user control.

Operation

3 Operation

This chapter will explain how to use the different menus.


3.1 Main menu



Picture 2: Menu main

The main menu is the most upper menu. From this main menu, the user can select a number of sub-menus. To select another sub-menu, use the cursor control keys UP and DOWN. When the desired sub-menu is selected, press the “enter sub-menu” function key. This is the function key with the icon left to it.

3.2 Measured values



Picture 3: Menu measured values

The measured values menu displays the current measured values. The main area can be divided into three columns. The menu can be left by pressing the “leave and sub-menu” function key.

Column 1: A graphical representation of the measured value. Below a list of the possible graphical representation with their description.


- | | | | |
|---|----------------|---|----------------|
|  | Wind |  | Sun intensity |
|  | Wind direction |  | Digital inputs |
|  | Temperature | | |

The unit were in the value of a particular sensor is measured, can be changed in the configuration menu section sensors.

Column 2: The alias of the sensor. The alias (description) of a sensor can be changed in the configuration menu section sensors.

Column 3: The actual measured values which will be updated every second. When a sensor is temporary disabled, the text "off" will be shown. When a sensor is defect, the text "defect" will be shown.

3.3 State of functions



Picture 4: Menu state of functions

The state of functions menu gives an overview of the function state. The main area can be divided into two sections: a detailed function description of current group and an active function overview.

3.3.1 Detailed functional description of current group

In this description the state of all functions of the current group will be shown. The header of this description shows the group alias. The different functions are ordered by priority in two columns. The function with the highest priority number, has the highest priority. The priority can be any number between 0 (lowest) and 255 (highest). Next to the priority, an icon is shown which represents the function. Below a description of all functions with their associated icon:

	Fire function		Rain function
	Window cleaning function		Temperature function
	Wind function		External inputs function
	Wind direction function		Hand function
	Clock function		Sun function

Next to the function type, the state of the function will be shown. Below a description of all possible function states:

- Function is active. A function will be active when during a predefined time the active conditions stay "true".
- Function is inactive. A function will be deactivated when during a predefined time the active conditions stay "false".
- Function is asleep. The function is enabled but will not perform any action. The time function will go to the sleep state when no timer program is stored. The sun function will go to the sleep state when the manual operation is activated.

Operation

 Function is in safety mode. The safety mode will be entered if one of the assigned sensors to this functions is defect or disabled.

 Function is disabled.

Next to the function state the motor action will be shown. Below a description of all possible motor actions:

 The motor action is up.

 The motor action is stop.

 The motor action is down.

3.3.2 Changing current group


With the function keys or with the cursor movement keys the current group of the detailed functional description can be changed.

 Next group. Show detailed description of next group.

 Previous group. Show detailed description of previous group.

3.3.3 Active function overview

This function shows an overview of the active functions for all groups. It also shows the current motor action, the position of the roller shutters and – when using venetian blinds – the angle of the blinds.



① Group of active functions.

② Active function, see detailed functional description for list of functions with their associated icons. When no function is active, this area is blank..


③ Angle of venetian blinds. When no venetian blinds are used, the symbol doesn't appear.

④ Position of the sunshade.

⑤ Motor action.

This description will be shown for each group.

3.3.4 Example




Picture 5: Menu state of functions – example


Priority	Function	Motor action
120	Window cleaning	UP
40	External inputs	UP
20	Sun	DOWN

Only the function with the highest priority will get the actual control. In the example for group 1 this will be the window cleaning function. When looking at the active function overview, this will be confirmed.

3.4 Control



Picture 6: Menu control – by hand function



Picture 7: Menu control – by sun function

The control menu gives the user the possibility to:

- Manual controlling (picture 6: Control menu – by hand function)
- Controlling the sun function (picture 7: Control menu – by sun function).

Operation

3.4.1 Control menu – by hand function

When controlling by hand function, the sun function is temporary disabled. The sunshade position can be controlled by hand using the following function keys:



Steer the sunshade up.



Stop the current motor action.
When no motor action is active, nothing will happen.



Steer the sunshade down.

3.4.2 Control menu – by sun function

When controlling by sun function, the sun function can be “forced” in a certain state using the following function keys.



Force the sun function in the inactive state
and the sunshade will be retracted.



Force the sun function in the active state
and the sunshade will be extended.

3.4.3 Type of control

The type of control can be changed by the following function keys.



Switch to control by sun function. This function key is only available when control by hand function is selected.



Switch to control by hand function. This function key is only available when control by sun function is selected.

3.4.4 Screen layout

The main area is divided into two sections. The layout has much similarities with the state of functions menu. The active function overview is the same as in the state of functions menu. In the active function overview can be seen which function is currently active. When a function with a higher priority than the hand or sun function is active, control by hand function or control by sun function has no use.

The description in the middle of the main area, shows for each group the type of control:



Control by sun function.




Control by hand function.

Next to the control type, the function state and the motor action is shown, same as in the state of functions menu detailed description.

3.4.5 Changing current group

To select another group to control, use the cursor movement keys. When group 1 is the current group, pressing DOWN will select group 2. When group 2 is the current group, pressing UP will select group 1.


3.5 Configuration



Picture 8: Menu configuration – enter

Within the configuration menu, a lot of settings can be made. For this reason the menu is password protected. For a detailed description of the configuration menu, see chapter 4, Configuration.

3.6 Logfile



Picture 9: Menu logfile

The logfile menu shows a list of all occurred errors. The last occurred error appears at the top of the list, the first occurred error at the bottom of the list. The logfile description consists out of three columns:

Date	Date when error occurred.
Time	Time when error occurred.
Description	Description of the error occurred. When the description does not fit in the logfile overview, the description will be truncated. This will be indicated with “..” at the end of the description.

3.6.1 Browsing the logfile

With the cursor movement keys UP and DOWN the current selection can be moved one up or one down. With the function keys it is possible to move the current selection one page up or down or show detailed information about the error.



Scroll one page up. When the first error in the logfile is selected, nothing will happen.



Scroll one page down. When the last error in the logfile is selected, nothing will happen.



Show detailed description about the select error.


Operation



Picture 10:
Menu logfile – detailed description

When the function key detailed information is pressed, a dialog window will be shown with detailed information about the error (see picture 10: Logfile menu – detailed description). The dialog window can be hide by pressing the function key next to the OK text.

3.7 Info




Picture 11: Menu info

The info menu shows the following information:

- Serial number The serial number of the Vesta Building Controller.
- Software Detailed information about the software version.
 - Version Software version
 - Date Software release date
 - Remarks Software remarks (in case of special software).
- Vestalon When the Vesta Building Controller is equipped with a Vestalon-module, detailed information about the Vestalon-module will be shown.
 - Version Software version
 - Date Software release date
 - Name Vestalon id name
 - Neuron ID Vestalon neuron id
- Project Project name description.
- Contact info Contact information who you can call for more information about the Vesta Building Controller.

4 Configuration



Picture 12: Menu configuration – enter

Within the configuration menu, a lot of settings can be made. For this reason the menu is protected by a password.

4.1 Password

To enter the configuration menu, a correct password must be entered. The default password is “usr” (without the quotes and in lower case). The password can be changed in the configuration menu section change password.


4.1.1 How to enter the password

As shown in picture 12, two dialog windows appear on the screen. The upper is the password input dialog window and the lower is the character select dialog window. With the cursor movement keys the character to insert can be selected in the character select dialog window. With the edit keys (plus or minus key) the selected character will be inserted. When entering a password, characters entered will be showed as “*”. The function keys have the following functionality:

- ←** Move the cursor within the edited text to the left.
- Move the cursor within the edited text to the right.
- home** Move the cursor within the edited text to the left position (the home position).
- del** Delete the character behind the cursor. If the cursor is at the end of the edited text, delete the character left to the cursor.
- Cancel** Cancel the text edit. Modifications to the text will be ignored.
- ok** Accept the edited text. Modification to the text will be taken over.

When the password is entered correctly and accepted, the configuration menu will appear.

Configuration




Picture 13: Menu configuration

When changes are made in the configuration, the function key "save settings" will be enabled.



Save changes made in the configuration. This function key is only activated when changes are made. Before leaving the configuration menu, changes must be saved, otherwise changes will be lost.

4.2 User interface



Picture 14: Menu user interface

Within the user interface menu, the following settings can be made.

Regional settings

Language Select language.
The following languages are implemented: english, german, dutch, french.

Screensaver


Enabled Enable or disable the screensaver functionality.
When the screensaver is disabled, the backlight of the display will always be on. It is not recommend to disable the screensaver. The lifetime of the backlight is limited.

Timeout When the screensaver is enabled, the timeout can be set from 1 to 60 minutes. When for the timeout time no key is pressed, the backlight will go off. When pressing a key again, the backlight will go on (the key pressed will be ignored).


Buzzer settings

Volume Set the volume of the buzzer.
The volume can be set from 0% to 100% with a resolution of 5%.

4.3 Time and Date



Picture 15:
Time and Date – set time



Picture 16:
Time and Date – set date

In the time and date menu, time and date can be set. The following paragraphs describes how.

4.3.1 Set time

The menu “set time” shows the default current time (see picture 15: Time and Date – set time). The clock will be updated every second. With the cursor movement keys, the following settings can be selected: hours, minutes and seconds. When changing the time with the edit keys, the clock stops ticking till the new time and date will be saved. At the bottom of the main area the new time and date will be show.

4.3.2 Set date

The menu “set date” shows the default current date (see picture 16: Time and Date – set date). With the cursor movement keys you can select between: month, year or day.

4.3.3 Function keys

The function keys within the menu “time and date” have the following functionality:



Switch to menu “set date”. This function key is only available in the menu “set time”.



Switch to menu “set time”. This function key is only available in the menu “set date”.



Save the changed time and date. This function key is only enabled when changes are made to time and/or date.

Configuration

4.4 Groups




Picture 17: Menu groups

The groups menu let you set the following:


- Type** Setting the type of the sunshade. You could select the types shade, shutter, venetian blind or screen.
- Alias** A description for the current group. Default the alias will be set to "Group n" where "n" is current group index (1...8). The alias can be changed by pressing the edit keys. The character dialog will appear (see paragraph 4.1.1, How to enter the password).
- Runtime** The runtime of a group. This is the time that it takes to steer the sunshade from the retracted position to the extended position. The runtime can be set from 1 to 3600 seconds.
- Up extra** With the up extra setting, the runtime for steering up can be extended. Normally, steering the sunshade down goes faster than steering the same sunshade up. This will be caused by the earth gravity. When setting up extra to 15% means that the runtime up will extended with 15% of the total runtime.
- Tilting time** The maximum tilting time, when using venetian blinds. The time that must be entered is the time that is needed to steer the venetian blind from the closed position to the completely open position. The tilting time can be set from 0.0 to 9.9 seconds with a resolution of 100 milliseconds.

4.6 Change password



Picture 18: Change password

In the menu change password, the password which gives access to the configuration menu, can be changed. First enter the old password, then enter and confirm the new password. When the new password is accepted, the following dialog will appear.



Picture 19: Change password – info


Saving the configuration (press save function key) you will also save the new password. When the configuration will not be saved, the old password will be retained.

4.6 Sensors

In the sensors section of the configuration menu the following settings can be made for each sensor:

- Unit The unit of the measured sensor value.
- Enabled If the current sensor is enabled or disabled.
- Alias A description for the current sensor.

4.6.1 Sonnensensoren



Picture 20: Menu sun sensors

Global settings


Unit The unit of the sun sensor can only be set to “klx”. Maybe that in the future the unit type for the sun sensor will be extended.

Sensor “n” settings

Enabled Enable or disable sensor “n”.
Alias A description for sensor “n”.

Configuration

4.6.2 Temperature sensors



Picture 21: Menu temperature sensors


Global settings

Unit The unit of the temperature sensors can be set to °C (degrees Celsius), °F (degrees Fahrenheit) and K (Kelvin).

Sensor “n” settings

Enabled Enable or disable sensor “n”.
Alias A description for sensor “n”.

4.6.3 Wind sensors



Picture 22: Menu wind sensors


Global settings

Unit The unit of the wind sensors can be set to m/s (metres per second), km/h (kilometres per hour), knots and bft (Beaufort).

Sensor “n” settings

Enabled Enable or disable sensor “n”.
Alias A description for sensor “n”.

4.6.4 Wind direction sensor



Picture 23: Menu wind direction sensor

Global settings

Unit

The unit of the wind direction sensor can be set to °(degrees) and N-E-S-W (North-East-South-West).

Sensor "n" settings

Enabled

Enable or disable sensor "n".


Alias

A description for sensor "n".

4.7 Functions

In the next paragraphs the configuration of the different functions will be explained.

4.7.1 Tilting function



Picture 24: Menu tilting function

The tilting functionality is normally wanted when using venetian blinds. The Vesta Building Controller supports two tilting types: fixed tilting and tilting during day. In this menu group both kinds of tilting can be configured for each group.

Configuration

Global settings

- Group Group selection.
- Alias Shows the alias of the current selected group.

Fixed tilting settings

- Enabled Enable or disable fixed tilting functionality. When fixed tilting is disabled, no fixed tilting command will be executed.
- Fixed The fixed tilting position. This position can be set from 0% to 100%. 0% means venetian blinds fully closed, 100% means venetian blinds fully opened.

Tilting during day settings

- Enabled Enable or disable the tilting during day functionality. When tilting during day is disabled, no tilting during day commands will be executed.
- Mode Select the way of regulating the venetian blinds. The possible options are:
 - Secure
Before regulating the tilting, a down command with a duration of the runtime will be executed.
 - Standard
Before regulating the tilting, a down command with a duration of the maximum tilting time will be executed.
 - Fast
Only adjust the tilting by steering up or down (dependence of last tilting position and new tilting position).

Tilting table

- Time For each month four tilting zones can be defined. Within this time-period for that specific month, the tilting will be set as programmed by the tilting parameter. For example figure 24 menu tilting function month january:
The first period of time of the daily tilting function starts at 9:00 o'clock with a tilting position of 50%. This position will be hold until the next period starts. The second period of time starts at 12:00 o'clock. At this time the tilting position changes to 75%. At 15:00 o'clock the third period of time get active and the tilting position will be set to 50%. The fourth period starts at 19:00 o'clock with a tilting position of 10%. This position will be hold until the first period of time at the next day starts. In this example the period starts at 9:00 o'clock with a tilting position of 50%.
Note that the period 1–4 of the programmable times must increase. That means period 2 must be later than period 1 and period 3 must be later than period 2.
- Tilting Set the tilting position for the particular time zone. The tilting position can be set from 0% to 100%.


Please remark that you only could configure the tilting function in this menu. The tilting function can be activated by the following 5 functions:

- Sun function
- External inputs function
- Clock function
- Temperature function
- Hand function

Assigning tilting to a function is only possible when that function satisfies the following conditions:

- Function action must be down.
- Function type must be running.

4.7.2 Sun function



Picture 25: Menu sun function

The sun function will steer the sunshade as function of the measured sun intensity.

Global settings

Group	Group selection.
Alias	Shows the alias of the current selected group.
Enabled	Enable or disable the sun function.

Sun threshold

Low	Sun threshold low value. When the sun intensity is below this threshold for the programmed inactive time, the sun function will become inactive. In that case the sunshade will be retracted (when no other function with a higher priority is active). The sun low threshold must always be below the high threshold.
High	Sun threshold high value. When the sun intensity is equal or higher than the programmed high threshold for the programmed active time, the sun function will become active. In that case the sunshade will be extended (when no other function with a higher priority is active). The sun high threshold must always be above the low threshold.

Assigned sensors

Sensor	Gives a list of all possible sensors which can be assigned to this function. When moving the cursor over the different sensor indexes, the alias will show the corresponding name of that sensor. The sensor index can have the following states:
--------	---

-  Sensor is not assigned to function, cursor is not on this sensor index.
-  Sensor is assigned to function, cursor is not on this sensor index.
-  Sensor is not assigned to function, cursor is on this sensor index.
-  Sensor is assigned to function, cursor is on this sensor index.

When assigning more than one sensor to this function, the highest measured value of the assigned sensors will be used.


Alias	When the cursor is on a sensor index, the alias shows the corresponding name of that sensor, otherwise this will be blank.
-------	--

Configuration

Function

- Active delay Set the function active time in minutes. When during this time the function conditions stay true (sun intensity equal or more than the sun threshold high level), the function becomes active.
- Inactive delay Set the function inactive time in minutes. When during this time the function conditions stay false (sun intensity below the low threshold), the function becomes inactive.
- Tilting Set the desired tilting type for the sun active state. This can be none, fixed or during the day.

4.7.3 Temperature function



Picture 26: Menu temperature function

The temperature function will steer the sunshade as function of the measured temperature.

Global settings

- Group Group selection.
- Alias Shows the alias of the current selected group.
- Enabled Enable or disable the temperature function.

Temperature settings

- Threshold Set the temperature threshold.
Set when the temperature function will become active.
- Active When below
The temperature function will become active when the actual temperature is below the programmed threshold.
When above
The temperature function will become active when the actual temperature is above the programmed threshold.


Assigned sensors

- Sensor Gives a list of all possible sensors which can be assigned to this function. When moving the cursor over the different sensor indexes, the alias will show the corresponding name of that sensor. When assigning more than one sensor to this function, the highest measured value of the assigned sensors will be used.
- Alias When the cursor is on a sensor index, the alias shows the corresponding name of that sensor, otherwise this will be blank.

Function

- Active delay Set the function active time in minutes. When during this time the function conditions stay true, the function becomes active.
- Inactive delay Set the function inactive time in minutes. When during this time the function conditions stay false, the function becomes inactive.
- Tilting Set the desired tilting type for the temperature active state. This can be none, fixed or during the day.

4.7.4 Wind-function



Picture 27: Menu wind function

The wind function will steer the sunshade as function of the measured wind speed.

Global settings

- Group Group selection.
- Alias Shows the alias of the current selected group.
- Enabled Enable or disable the wind function.

Wind settings

- Threshold Set the wind speed threshold. The wind speed threshold must always be above the wind speed threshold of the wind direction function.

Assigned sensors

- Sensor Gives a list of all possible sensors which can be assigned to this function. When moving the cursor over the different sensor indexes, the alias will show the corresponding name of that sensor. When assigning more than one sensor to this function, the highest measured value of the assigned sensors will be used.
- Alias When the cursor is on a sensor index, the alias shows the corresponding name of that sensor, otherwise this will be blank.

Function

- Active delay Set the function active time in seconds. When during this time the function conditions stay true (wind speed equal or more than the threshold level), the function becomes active.
- Inactive delay Set the function inactive time in minutes. When during this time the function conditions stay false (wind speed below threshold), the function becomes inactive.

Configuration

4.7.5 Wind direction function



Picture 28: Menu wind direction function

The wind direction function will steer the sunshade as function of the wind speed in combination with the wind direction.

Global settings

- Group: Group selection.
- Alias: Shows the alias of the current selected group.
- Enabled: Enable or disable the wind direction function.

Wind protection

- From: Set the start angle of the protected wind direction area.
- Up to: Set the stop angle of the protected wind direction area.
- Threshold: Set the wind speed threshold. The wind speed threshold must always be below the wind speed threshold of the wind function.


Assigned sensors

- Sensor: Gives a list of all possible sensors which can be assigned to this function. When moving the cursor over the different sensor indexes, the alias will show the corresponding name of that sensor. When assigning more than one sensor to this function, the highest measured value of the assigned sensors will be used.
- Alias: When the cursor is on a sensor index, the alias shows the corresponding name of that sensor, otherwise this will be blank.

Function

- Active delay: Set the function active time in seconds. When during this time the function conditions stay true (wind speed equal or more than the threshold level and wind direction inside protected area), the function becomes active.
- Inactive delay: Set the function inactive time in minutes. When during this time the function conditions stay false (wind speed below threshold or wind direction outside protected area), the function becomes inactive.

4.7.6 Rain function



Picture 29: Menu rain function

The rain function will steer the sunshade as function of the rain.


Global settings

- Group Group selection.
- Alias Shows the alias of the current selected group.
- Enabled Enable or disable the rain function.

Function

- Active delay Set the function active time in seconds. When during this time the function conditions stay true (rain), the function becomes active.
- Inactive delay Set the function inactive time in minutes. When during this time the function conditions stay false (no rain), the function becomes inactive.

4.7.7 Window cleaning function



Picture 30: Menu window cleaning function

The window cleaning function will steer the sunshade as function of the window cleaning input.

Global settings

- Group Group selection.
- Alias Shows the alias of the current selected group.
- Enabled Enable or disable the window cleaning function.


Function

- Active delay Set the function active time in minutes. When during this time the function conditions stay true (window cleaning input active), the function becomes active.

Configuration

Inactive delay Set the function inactive time in minutes. When during this time the function conditions stay false (window cleaning input inactive), the function becomes inactive.

4.7.8 External inputs function



Picture 31: Menu external inputs function

The external inputs function will steer the sunshade as function of the external inputs.


Global settings

Group Group selection.
Alias Shows the alias of the current selected group.
Enabled Enable or disable the external inputs function.

Function

Active delay Set the function active time in seconds. When during this time the function conditions stay true (external input UP/DOWN active), the function becomes active.
Inactive delay Set the function inactive time in seconds. When during this time the function conditions stay false (external input UP/DOWN inactive), the function becomes inactive.
Tilting Set the desired tilting type for the external inputs function active state. This can be none, fixed or during the day.

4.7.9 Hand function



Picture 32: Menu hand function

The hand function will steer the sunshade as function of hand given commands.


Global settings

Group	Group selection.
Alias	Shows the alias of the current selected group.
Enabled	Enable or disable the hand function.

Function

Inactive delay	Set the function inactive time in seconds. When during this time the function conditions stay false, the function becomes inactive.
Tilting	Set the desired tilting type for the external inputs function active state. This can be none, fixed or during the day.

4.7.10 Fire function



Picture 33: Menu fire function

The fire function will steer the sunshade as function of the fire input.

Global settings


Group	Group selection.
Alias	Shows the alias of the current selected group.
Enabled	Enable or disable the fire function.

Function

Active delay	Set the function active time in minutes. When during this time the function conditions stay true (fire), the function becomes active.
Inactive delay	Set the function inactive time in minutes. When during this time the function conditions stay false (no fire), the function becomes inactive.

Configuration

4.7.11 Clock function



Picture 34: Menu clock function

The clock function will steer the sunshade as function of programmed time slots.

Global settings

- Group Group selection.
- Alias Shows the alias of the current selected group.
- Enabled Enable or disable the clock function.

Clock moment

- Moment Select the time slot to modify.
- Enabled Enable or disable the current selected time slot. When a time slot is disabled, it will not be executed. In some cases it can be handy to temporarily disable one or more time slots.
- Start Set the start day and time for the current time slot.
- Stop Set the stop day and time for the current time slot. A time slot may be programmed over one or more days.
- Action Set the command action to perform when this time slot becomes active. The command action can be UP or DOWN.
- Type Set the command type: running or continuously.
- Blocking Enable or disable the blocking relays. Setting the blocking is only possible when the command type is running. When blocking is enabled, no individual control in the room of the particular group is possible. The sunshade will be blocked. When blocking is set to no, individual control in the room of the particular group is possible.
- Tilting Set the desired tilting type for this time slot. This can be none, fixed or during the day.

In total 28 time slots can be programmed. Time slots may not overlap each other.

5 Troubleshooting

Fault	Possible cause	Remedy
The device doesn't work at all.	No power supply or defective fuse.	Check if the green LED on the front is on. If not check the power supply and fuse.
The display is very difficult to read.	The backlight is off.	Press any key to activate the backlight.
The relays switch but nothing happens.	There is no voltage applied on the relay commons, or the ground is not connected.	Apply a voltage on the commons or check the ground.
Not all outputs are working properly.	Not all the terminals are connected or not all groups are enabled.	Check if all terminals are connected. Groups are activated?
The message "Sun sensor xx defect" appears.	Bad connection or short circuit.	Check sun sensor connection.
The message "Wind sensor xx defect" appears.	Bad connection or short circuit Jumper J1 / J2 in wrong position.	Check wind sensor connection and jumper placement (chapter 1.2.3).
The message "Wind direction defect" appears.	Bad connection or short circuit Jumper J3 in wrong position.	Check wind direction connection and jumper placement (chapter 1.2.4).
The message "Temperature sensor xx defect" appears.	Bad connection or short circuit.	Check the temperature sensor connections.
The sun shines but the sunshades are not extended.	Sun sensor assignment not correct.	Check if the sun sensors are assigned to the correct groups.
	The manual operation is active.	Check if the device is in automatic operation (Menu: CONTROL)
	A function with a higher priority is active.	Check if a function with a higher priority is active (Menu: STATE OF FUNCTIONS).
	The sun intensity is lower than the set threshold.	Check the threshold (Menu: CONFIGURATION).

Technical data

6 Technical data

Power supply:	230 V~, 50 Hz
Rated power:	30 W
Fuse:	500 mA _T , 5 × 20 mm
Output:	Relay output, potential-free
Maximum load::	12A, 230 V~, cos φ ≥ 1 12A, 24 V=
Switching time:	0.1s – 3600s 0.1s – 99.9s in steps of 0.1s for tilting time 0.1s – 1s in steps of 0.1s for running time 1s – 3600s in steps of 1s for running time
Operating temperature:	0 °C bis +40 °C
Dimensions:	323 mm × 326,7 mm × 85 mm (without cable inlets)
IP class:	IP54 (unused cable inlets must be closed)
Cable inlets:	14 × PG9 top side 10 × PG11 bottom side

The information in this operating instruction is subject to change at any time and without notice!